SERVICE LETTER 220

Aviat Husky 2100A Hydraulic Pump Replacement

Aircraft Makes/Model(s):	Float Model(s):	Compliance: Optional	By: MAB
Aviat Husky A-1, A-1A, A-1B, A-1C,	2100A	Part Number: 1011613	Approved: SDW
and A-1 with Aviat SB 13		Date: 5/7/2021	Revision: A

LOG OF REVISIONS

Revision	Description	
A	Initial release	5/7/2021

FAA approval has been obtained for technical data in this publication that affects STC or TSO design compliance.

EFFECTIVITY:

This service letter applies to Aviat Husky models A-1, A-1A, A-1B, A-1C, and A-1 with Aviat SB 13 with Wipline 2100 Amphibian Floats installed per STC SA00637CH.

COMPLIANCE:

Optional compliance

BACKGROUND:

The standard Hydraulic Pump Assembly p/n 21A09000-195 and the extended baggage version hydraulic pump p/n 21A09000-288 have both been discontinued. This service letter provides the option to replace them with a new standard pump p/n 1011543 or with the extended baggage version pump p/n 1011541.

COMPLIANCE METHOD:

Install provided parts as shown in the Work Instruction section of this service letter.

APPROXIMATE SHOP HOURS:

The work instruction for this service letter will take approximately 8 labor hours.

WEIGHT AND BALANCE CHANGE:

Side Mount +4 lbs, F.S. 124.97

Extended Baggage +4 lbs, F.S. 111.35

WARRANTY INFORMATION:

This service letter does not include warranty for labor and parts.


TECHNICAL DATA:

Copies of this service letter, associated service kit (if applicable), float service manual, and float parts manual are available at www.wipaire.com.




ITEMS PROVIDED IN SERVICE KIT 1011613-01 (STANDARD PUMP ONLY)

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1011543	ASSEMBLY, HYDRAULIC POWER PACK, 12V




DISCONTINUED STANDARD
HYDRAULIC PUMP 21A09000-195




NEW STANDARD HYDRAULIC PUMP 1011543

ITEMS PROVIDED IN SERVICE KIT 1011613-02 (EXTENDED BAGGAGE PUMP ONLY)

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1011541	ASSEMBLY, HYDRAULIC POWER PACK, 12V




DISCONTINUED EXTENDED BAGGAGE
HYDRAULIC PUMP 21A09000-288



NEW EXTENDED BAGGAGE HYDRAULIC PUMP 1011541







Work Instruction

Standard Pump Installation:

- 1. Disconnect aircraft battery.
- 2. Disconnect single pin Molex connector for GA1 wire.
- 3. Disconnect 4 pin CPC connector from hydraulic power pack assembly 21A09000-195.
- 4. If aircraft has a hydraulic low level warning system, disconnect wire harness from sensor in reservoir.
- 5. Drain hydraulic fluid from hydraulic power pack reservoir.
- 6. Disconnect and cap 21A09000-208 hydraulic line from reservoir to emergency hand pump.
- 7. Disconnect and cap 21A09000-204 hydraulic lines from pump up and dn ports to cross fitting.
- 8. Unbolt and remove hydraulic power pack 21A09000-195 from aircraft fuselage.
- 9. Install new hydraulic power pack 1011543 onto aircraft fuselage using existing hardware.
- 10. Re-install hydraulic lines 21A09000-204 to pump manifold up and dn ports.
- 11. Re-install hydraulic line 21A09000-208 to pump reservoir fitting.
- 12. If aircraft has a hydraulic low level warning system, reconnect wire harness to sensor in new reservoir.
- 13. Re-install 4 pin CPC connector. See electrical schematic.
- 14. Cut single pin Molex connector from GA1 wire. Install 73F-250-32NL connector onto GA1 wire. Connect GA1 wire to power wire on hydraulic pump assembly. See electrical schematic.
- 15. Reconnect aircraft battery, service pump reservoir with MIL-H-5606 hydraulic fluid, and perform a retraction/extension test to make sure system is functioning correctly. Watch the system for leaks and add MIL-H-5606 hydraulic fluid as needed.

Extended Baggage Installation:

- 1. Disconnect aircraft battery.
- 2. Disconnect single pin Molex connector for GA1 wire.
- 3. Disconnect 4 pin CPC connector from hydraulic power pack assembly 21A09000-288.
- 4. If aircraft has a hydraulic low level warning system, disconnect wire harness from sensor in reservoir.
- 5. Drain hydraulic fluid from hydraulic power pack reservoir.
- 6. Disconnect and cap 21A09000-208 hydraulic line from reservoir to emergency hand pump.
- 7. Disconnect and cap 21A09000-204 hydraulic lines from pump up and dn ports to cross fitting.
- 8. Unbolt and remove hydraulic power pack 21A09000-288 from 21A09000-290 lower angle mount and 21A09163-095 upper angle mount.
- 9. Install new hydraulic power pack 1011541 onto upper and lower angle mounts with existing hardware.
- 10. Re-install hydraulic lines 21A09000-204 to pump manifold up and dn ports.
- 11. Re-install hydraulic lines 21A09000-208 to pump reservoir fitting.
- 12. If aircraft has a hydraulic low level warning system, reconnect wire harness to sensor in new reservoir.
- 13. Re-install 4 pin CPC connector. See electrical schematic.
- 14. Cut single pin Molex connector from GA1 wire. Install 73F-250-32NL connector onto GA1 wire. Connect GA1 wire to power wire on hydraulic pump assembly. See electrical schematic.
- 15. Reconnect aircraft battery, service pump reservoir with MIL-H-5606 hydraulic fluid, and perform a retraction/extension test to make sure system is functioning correctly. Watch the system for leaks and add MIL-H-5606 hydraulic fluid as needed.

Revision A Page 4 of 5 P/N 1011613



Aircraft Closing & Return to Service

1. Upon completion of inspection, enter information in Aircraft Logbook for completion of Wipaire Service Letter 220