

WIPAIRE, INC.
INVER GROVE HEIGHTS, MN

DATE: Sept. 15, 2003

SERVICE KIT: #43

SUBJECT: Addition of nose gear pivot block shim

MODEL: 2100 and 2350 amphibious floats

<u>Item</u>	<u>Quantity</u>	<u>Part No.</u>	<u>Description</u>
1.	2	21A07154-019	Shim
2.	4	AN5-20A	Bolt
3.	4	AN5-15A	Bolt
4.	16	NAS1149FO563P	Washer
5.	16	NAS1149FO532P	Washer
6.	8	AN365-524	Nut
7.	1	#62	Service Letter

INSTRUCTIONS:

1. Raise front of floats so nose wheel does not contact ground.
2. Remove existing pivot block from nose spring lower end.
3. Install 21A07154-019 shim between spring and pivot block per drawing below.
4. Repeat on opposite side.
5. Lower floats to ground.

